


# CETTA 35, 50 - ECONOMY

## Control



### DESCRIPTION OF CONTROL BY CORD WITH BRAKE:

Tilt the lamellas using the control ropes for the tilting mechanism. The blind is moved up and down by drawing up the rope connected to the lower profile of the grid. For lifting and lowering, it is first necessary to release the brake by drawing the cord in a diagonal direction to the centre of the blind. The blind is lowered by releasing the rope; lifting into the requested position is achieved by drawing in the rope, drawing the cord into the centre, the consequent release will fix (secure) the brake.

Recommendation: when lifting and lowering the blind, tilt the lamellas into the open position.

## 2. MAINTENANCE

The product does not require any extraordinary maintenance or lubrication of control mechanisms.

In the case of dirtying (dust), regularly use a fine brush or a slightly adjusted manual vacuum cleaner.


During common cleaning regularly wipe the surface with a cloth or a wet soft textile or sponge. Use only soap solutions without chemical ingredients at a temperature of up to 30°C.

Do not use aggressive detergents, such as organic solvents, cleaning sand and cleaning pastes which develop vapours and strong alkali cleaning detergents.

## NOTIFICATION:

Ensure careful cleaning of shading lamellas to prevent jamming or other damage.  
When cleaning windows, set the product into a position to prevent damage and any interference while cleaning.  
Protect the product against dirtying during reconstruction and painting.

## 3. SAFETY INSTRUCTIONS

**Important note**

Pursuant to the EN 13 120 standard, we hereby call your attention to possible hazards posed by the use of pull cords and chains!

## Safety instructions / strangulation hazard:

- Young children have been strangled by loops in pull-cords, chains and tapes, and cords that operate the product.
- To avoid strangulation and entanglement, keep cords out of the reach of young children. Cords may become wrapped around a child's neck.
- Move beds, cots and furniture away from window covering cords.  
Install the enclosed safety components to make sure cords do not twist and create a loop.
- Do not use force when handling the product if any obstacle prevents its motion.
- Do not attach any items to the product (particularly on the lamellas, control cords).
- Prevent mechanical stress and damage to the product.
- For products controlled by cords, keep the cords beyond the reach of children to prevent entangling and jamming.
- Handle the product carefully, especially during cleaning.
- Wind the pull cords to the reel after each use!

## FOR PRODUCTS WITH MOTOR-DRIVEN DRIVES:

- To set the electric control of the product, follow the manual for this device that was delivered by the supplier.
- Do not allow children to play with the control equipment. Keep the remote control out of the reach of children.
- Check the installation for damage to inlets.
- For the inspection or maintenance of electrical parts, the product must be disconnected in an appropriate manner from the electricity supply.

## NOTIFICATION:

Electrical installation, assembly and maintenance must only be performed by fully-qualified persons who are authorized and capable of the stated actions.

In the case of a defect or mechanical damage to the product, prevent any further use.

## NOTES:

- If the product is not functional, contact the seller or the firm which assembled the product.

- The display of the product may slightly differ from the actual version. The producer reserves the right to make changes.
- After termination of the service life, do not dispose of in communal waste. Materials used can be separated and handed over in accordance with the valid regulations on waste and environmental protection. Information on waste collection points can be obtained from the local administration office.